


Product data sheet

Rocker for KNX push-button 1-gang



Reference number

LS 101

1-gang rocker

for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST, LS CD 1091 1TE

Duroplastic (scratch-proof) glossy

Colour::

ivory

Material:

duroplastic



Individual colour printing possible