

Product data sheet

Rocker with lens and arrow symbols for KNX push-button 1-gang



Reference number
AL 101 KO5P AN
1-gang rocker with lens and arrow symbols
for JUNG HOME push-button 1-gang, battery-powered, ref.-no.: BT LS CD 1001 for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST
Metal versions
Colour:: anthracite (aluminium lacquered)
Material: aluminium lacquered