

# Product data sheet

Rocker for KNX push-button 1-gang



## Reference number

LC 101 212

## 1-gang rocker

for KNX push-button 1-gang ref.-no.: LS CD 1071 1ST, LS CD 1091 1ST, LS CD 1091 1TE

## matt lacquered

## Colour::

céruléen vif

## Material:

duroplastic lacquered



Individual colour printing possible