


Product data sheet

Rocker with lens and arrow symbols for KNX push-button 2-gang



Reference number
LC 102 KO5P 249
2-gang rocker with lens and arrow symbols
for JUNG HOME push-button 2-gang, battery-powered, ref.-no.: Art.-Nr.: BT LS CD 1002 for KNX push-button 2-gang ref.-no.: LS CD 1072 1ST, LS CD 1092 1ST
matt lacquered
Colour: vert olive vif
Material: duroplastic lacquered