

Product data sheet

Rocker for KNX push-button 2-gang



Reference number

CD 102 SW

2-gang rocker

for KNX push-button 2-gang ref.-no.: LS CD 1072 1ST, LS CD 1092 1ST, LS CD 1092 1TE

Duroplastic (scratch-proof) glossy

Colour:

black

Material:

duroplastic



Individual colour printing possible