

WIRELESS 2- OR 4-WAY PUSHBUTTON 45 X 45 MM BELGIUM, WITHOUT FRAME, WITHOUT BATTERY AND WIRE FT4B-



Wireless pushbutton with intermediate frame and rocker (without frame)



Wireless pushbutton with intermediate frame and double rocker (without frame)



Manuals and documents in further languages:
<https://eltako.com/redirect/FT4B->

FT4B-



Wireless 2- or 4-way pushbutton 45 x 45 mm Niko Belgium. Generates the power for wireless telegrams itself when the button is pressed, therefore there is no connecting wire and no standby loss.

FT4B-cr	Wireless 2- or 4-way pushbutton 45 x 45 mm Belgium, w/o frame, niko cream, without battery and wire	Art. No. 30000229	62,00 €/pc.
FT4B-na	Wireless 2- or 4-way pushbutton 45 x 45 mm Belgium, w/o frame, niko anthracite, without battery and wire	Art. No. 30000240	62,00 €/pc.
FT4B-nw	Wireless 2- or 4-way pushbutton 45 x 45 mm Belgium, w/o frame, niko white, without battery and wire	Art. No. 30000221	62,00 €/pc.