



Wireless pushbutton with rocker
(without frame)



Manuals and documents in further
languages:
[https://eltako.com/redirect/
F2T55EBT-](https://eltako.com/redirect/F2T55EBT-)

F2T55EBT-



Wireless 2-way Bluetooth pushbutton 55 x 55 mm.

Wireless pushbutton insert with EnOcean energy generator. Generates the power for wireless telegrams itself when the button is pressed, therefore there is no connecting wire and no standby loss.

The scope of supply comprises a rocker, the mounting base, an attachment frame for PTM modules with EnOcean module inserts PTM216B and an adhesive foil.

The mounting plate can be screwed over a flush-mounting box with a screw spacing of 60 mm or screwed on a flat surface. The wireless pushbutton can be glued to the wall, on glass or on furniture using the enclosed adhesive foil.

Wireless pushbuttons with rocker can transmit two evaluable signals: press rocker up or down.

F2T55EBT-am	Wireless 2-way Bluetooth pushbutton, without frame, anthracite mat	Art. No. 30000608	63,60 €/pc.
F2T55EBT-pg	Wireless 2-way Bluetooth pushbutton, without frame, polar white glossy	Art. No. 30000607	63,60 €/pc.
F2T55EBT-pm	Wireless 2-way Bluetooth pushbutton, without frame, polar white mat	Art. No. 30000606	63,60 €/pc.
F2T55EBT-wg	Wireless 2-way Bluetooth pushbutton, without frame, pure white glossy	Art. No. 30000605	63,60 €/pc.



ATTENTION: Not compatible with EnOcean wireless actuators!